

Young Chang Distributors .....	iii
PC88 Specifications .....	iv
Physical .....	iv
Electrical .....	iv
Environmental .....	iv
Audio .....	iv
<b>Introducing the PC88 .....</b>	<b>1-1</b>
For People Who Never Read Manuals. ....	1-1
Unpacking the Unit. ....	1-2
Setup .....	1-2
Installing the Music Rack .....	1-3
Demo Sequence .....	1-3
Internal Voices .....	1-4
Assigning Controllers .....	1-4
MIDI Setups.....	1-5
Effects .....	1-7
Just the Beginning! .....	1-7
A Note About the VGM Board and the PC88mx .....	1-7
Checking Battery Voltage Level.....	1-8
<b>Setup, Connections, and Controls .....</b>	<b>2-1</b>
Setting Up the PC88.....	2-1
Connections.....	2-1
Power .....	2-1
Audio.....	2-1
Pedals .....	2-2
MIDI .....	2-2
Front Panel Controls .....	2-3
Display (LCD) .....	2-3
Cursor Buttons .....	2-3
Sound/Setup Select .....	2-4
Zone Buttons.....	2-4
Zone Parameters.....	2-5
Data Entry .....	2-7
Intuitive Entry .....	2-7
Jump Editing .....	2-9
Assignable Controllers, Buttons, and Wheels.....	2-9
Master Volume.....	2-10
Panic.....	2-10
Effects .....	2-10
<b>Internal Voices .....</b>	<b>3-1</b>
Program Numbers and Other Ways of Selecting Voices.....	3-2
Customizing the Internal Voices Mode .....	3-3
440-Tuned Piano Voices.....	3-3
Ride Cymbal and Metronome Click .....	3-3
The VGM Banks .....	3-4

<b>Setups and Zones.....</b>	<b>4-1</b>
Analyzing a Setup .....	4-1
Selecting Parameters .....	4-2
Selecting Zones .....	4-2
I Don't Hear a Zone: Is It Active (But Not Soloed), Muted, or Off? .....	4-3
Creating a Setup from an Internal Voice .....	4-4
<b>Zone Parameters .....</b>	<b>5-1</b>
Zone Parameters and Internal Voices .....	5-1
MIDI Transmit .....	5-2
MIDI Channel .....	5-2
Destination .....	5-2
Pitchbend Range .....	5-2
Program .....	5-3
Bank .....	5-3
Entry Transmit .....	5-4
Bank Mode .....	5-5
Program Number Display .....	5-5
Program Name Display .....	5-6
Key Range .....	5-6
Low, Hi .....	5-6
Note Map .....	5-6
Transpose .....	5-7
Velocity .....	5-8
Velocity Scale .....	5-8
Velocity Offset .....	5-8
Velocity Curve .....	5-9
Velocity Minimum, Velocity Maximum .....	5-10
Controllers .....	5-11
Getting Around .....	5-12
The Continuous Controllers .....	5-12
MIDI Controllers and Other Parameters .....	5-13
Scaling .....	5-14
Entry and Exit Values .....	5-15
The Switch Controllers .....	5-15
Do These Parameters Always Mean Something? .....	5-16
Do I Need All Those Pedals? .....	5-17
Multiple Controllers .....	5-17
Copying Parameters .....	5-17
Storing a Setup .....	5-19
Names .....	5-19
Dumping a Setup .....	5-20
Deleting a Setup .....	5-20
<b>The Arpeggiator .....</b>	<b>6-1</b>
Arpeggiator Active .....	6-2
Key Range .....	6-2

Zone Enable .....	6-2
Latch Mode .....	6-3
Play Order .....	6-3
Beats.....	6-4
Initial Tempo.....	6-4
Duration .....	6-4
Velocity Mode and Fixed Velocity .....	6-4
Note Shift .....	6-4
Shift Limit .....	6-5
Limit Option.....	6-5
Glissando.....	6-6
Available MIDI controllers .....	6-6
Copying the Arpeggiator.....	6-6
<b>Effects Editing .....</b>	<b>7-1</b>
Internal Effects.....	7-2
Internal Reverb Wet.....	7-2
Internal Reverb Time .....	7-2
Internal Effects Wet .....	7-2
Internal Effects Delay .....	7-2
Saving Effects .....	7-2
VGM Effects .....	7-3
Copying Effects .....	7-3
Effects and Drum Sounds .....	7-3
MIDI Control of Effects.....	7-4
Transmitting PC88 Effects Settings to a Sequencer .....	7-4
<b>MIDI Receive.....</b>	<b>8-1</b>
Channel On/Off.....	8-1
Program.....	8-1
General MIDI Considerations .....	8-2
<b>Global Parameters .....</b>	<b>9-1</b>
Local Control .....	9-2
Clock .....	9-2
Transmit Clock.....	9-2
Touch .....	9-2
Effects Change Mode.....	9-2
Change Setups.....	9-3
Setup Change Channel.....	9-3
MIDI In .....	9-3
Tuning and Receive Transpose .....	9-4
Bank Select Control .....	9-4
All Notes Off.....	9-4
General MIDI.....	9-4
Device ID .....	9-4
Transmit Buttons.....	9-5
Transmit Reverb Sysex .....	9-5

Memory Available .....	9-5
Reset PC88 .....	9-5
Dump all Setups .....	9-5
MIDIScope .....	9-6
<b>PC88 in the Real World.....</b>	<b>10-1</b>
At a Gig .....	10-1
In the Recording Studio .....	10-1
In the MIDI Composing Studio .....	10-2
In the Home .....	10-2
<b>Internal Voices.....</b>	<b>A-1</b>
<b>VGM Board Voices .....</b>	<b>B-1</b>
General MIDI voices .....	B-1
Expansion voices .....	B-2
<b>Drum sounds.....</b>	<b>C-1</b>
General MIDI .....	C-1
Kurzweil Drums .....	C-3
Latin Percussion .....	C-5
Orchestral Percussion.....	C-6
<b>Effects Algorithms.....</b>	<b>D-1</b>
<b>MIDI Setups.....</b>	<b>E-1</b>
Standard Setups .....	E-1
VGM Setups.....	E-3
Application Notes .....	E-4
Default Setup Parameters (Generic Template) .....	E-5
Default Controller Assignments (Internal Voices) .....	E-6
Setup Template .....	E-6
<b>Continuous Controllers in the MIDI Specification.....</b>	<b>F-1</b>
The first 64: 14-bits? .....	F-1
The Switches: 64-69.....	F-2
Sound Controllers: 70-79 .....	F-3
Controllers 80-97 .....	F-4
Registered and Non-Registered Parameters: Controllers 98-101 .....	F-4
102-119: Uncharted Territory .....	F-5
120-127: Mode Messages .....	F-6
<b>PC88 Internal Diagnostics.....</b>	<b>G-1</b>
Entering Diagnostics .....	G-1
Running the Debug Sequence .....	G-1
Exiting Diagnostics .....	G-2